



Note: When power is first applied or Wheel Detection Module is programmed it must be reset to enable the Switch Machine.



R A I L W A Y T E C H N O L O G Y , I N C O R P O R A T E D

TITLE	DESCRIPTION	DATE	PAGE
300/2	ELECTRICAL SCHEMATIC - WHEEL DETECTOR CIRCUIT	1/15/2008	1 OF 3





2 Detector Wiring Circuit




R A I L W A Y T E C H N O L O G Y I N C O R P O R A T E D

TITLE	DESCRIPTION	DATE	PAGE
300/2	ELECTRIC SCHEMATIC - SENSOR CONNECTIONS USING OKONITE H/D CABLE	10/26/2009	1 OF 1


Right & Left Hand Switches



Cross-Over



Derail



R A I L W A Y T E C H N O L O G Y I N C O R P O R A T E D

TITLE	DESCRIPTION	DATE	PAGE
300/2	Sensor Location ID # Assignments	1/15/2008	3 OF 3