


## 3-Detector wiring circuit

Additional Sensors can be added by wiring them parallel to the Main Module or to other Sensors.

### **Important:**

All shield wires or extra conductors inside the cable must be tied together inside each sensor being daisy-chained and landed on Battery Negative (-12vdc) inside the switch machine



R A I L W A Y T E C H N O L O G Y I N C O R P O R A T E D

TITLE	DESCRIPTION	DATE	PAGE
300/3	MM4Z ELECTRIC SCHEMATIC - SENSOR CONNECTIONS USING OKONITE H/D CABLE	6/10/2013	2 OF 3